


# Monkey MOMETER PRO

## QUICK TIPS




The **Monkey MOMETER PRO** is best installed in a well-lit room indoors with a consistent ambient temperature.



- NO BRIGHT LIGHTING DIRECTLY ABOVE THE UNIT



- NO WIND GUSTS OR EXHAUST VENTS INTO THE ROOM



- BE AWARE OF HIGH INTENSITY OVERHEAD HEATING AND OVERHEAD HEATING DUCTS IN GENERAL

The **Monkey MOMETER PRO** is best used on a person who has acclimatised to the room that the device is installed in, which can take a few minutes in some cases.



- THE DEVICE WILL NOT SCAN SOMEONE WITH A WIND CHILL



- IT IS BEST USED ON A PERSON WHO HAS REMOVED A BEANIE OR SCARF



- THE DEVICE IS NOT A MEDICAL DEVICE

The **Monkey MOMETER PRO** is shipped with a “face mask detection” configuration



- ADVANCED INSTALLATION OR DEVICE OPTIMISATION HAS TO BE QUOTED ON A CASE BY CASE BASIS



- *Monkey Vision* WILL ARRANGE AN INSTALLER TO QUOTE – THIS CAN TAKE UP TO 10 BUSINESS DAYS



- DEVICE CAN BE INSTALLED TO OPERATE AN ELECTRIC DOOR LATCH OR MAGNETIC LOCK



- DEVICE CAN BE OPTIMISED FOR FACIAL RECOGNITION – *Monkey Vision* CAN PROVIDE INSTRUCTION MANUALS



- DEVICE CAN BE PAIRED WITH A 4G ROUTER TO SEND PUSH NOTIFICATIONS TO AN APP FOR BLACKLIST ALERTS

The **Monkey MOMETER PRO** stores all records internally and is a stand-alone device

- THE DEVICE CAN ONLY BE ACCESSED VIA THE ETHERNET PORT ATTACHED TO THE DEVICE – EITHER DIRECTLY, OR VIA A NETWORK
- ONLY A BLACKLISTED PERSON WILL BE PUSHED OUTSIDE OF THE DEVICE, IF CONFIGURED AND CONNECTED TO A NETWORK

The **Monkey MOMETER PRO** can be used to confirm time of access to a site (Time & Attendance)

- EACH PERSON SCANNED IS RECORDED IN THE DEVICE AND IS TIME & DATE STAMPED, THESE RECORDS CAN BE EXPORTED INTO MS EXCEL FOR COMBINATION WITH OTHER DATA
- TO USE FOR “TIME & ATTENDANCE” THE EMPLOYEES WOULD NEED TO SCAN IN AND OUT OF THE SITE WOULD REQUIRE MULTIPLE DEVICES.
- IF CONFIGURED FOR FACIAL RECOGNITION, A PERSON’S NAME AND EMPLOYEE RECORD CAN BE INCLUDED IN THIS DATA